





# PART LIST

- |    |                      |      |               |
|----|----------------------|------|---------------|
| 1  | PIC 16F87 18DIP      | 8    | 10kΩ 1/4W     |
| 1  | Linx LR TXM          |      |               |
| 1  | Linx LR RXM          | 6-8" | 50Ω coax      |
| 1  | Philips SA630 RF SW. |      |               |
|    |                      |      | 50Ω antenna   |
|    |                      |      | (300-450 MHz) |
| 1  | 74LS138 3-to-8       |      |               |
| 1  | 74LS148 8-to-3       |      |               |
| 1  | 74LS149 2-to-4       |      |               |
| 2  | 74LS04 NOT-6         |      |               |
| 1  | LM317 voltage reg.   |      |               |
| 10 | 2SK3041 power MOSFET |      |               |