





PART LIST

1	PIC 16F87 18DIP	18	10kΩ 1/4 W
1	Linx LR TXM	22	100kΩ 1/4 W
1	Linx LR RXM	1	680 1/4 W
1	Philips SA630 RF SW.	1	330 pot. 1/4 W
1	74LS138 3-to-8		
1	74LS148 8-to-3		
1	74LS149 2-to-4	8	SPST NO pushbutton
1	74LS04 NOT-6		50Ω coax
1	LM317 voltage reg.		50Ω whip antenna
10	2SK3047 power MOSFET		
10	2N7000 signal MOSFET		